

HOW THE SAV SLIDER ANCHOR WORKS



1. If the plough of the anchor of the anchor is stuck on the bottom, retrieval will not be possible while the shackle and chain are at the top end of the shank.

2. To move the shackle and chain toward the bottom end of the shank, drive the boat directly over the anchor's position and continue forward.

3. Forward motion will cause the shackle and chain to slide down to the bottom end of the shank. The force from this angle will pull the anchor free.

